


## Easyglaze System

### a rigid self-adhesive system

The Easyglaze double glazing system comprises two rigid PVC sections, a base section and a cover strip. It is sold in packs of 10 x 2.44m or 10 x 1.22m lengths, in white and brown. Mitre beading is also supplied to assist you in cutting neat, accurate corners. This product is fixed to the frame by self-adhesive tape which is mounted on the base section. **We DO NOT recommend the use of glass with this product.**



The Easyglaze system is for internal use only, fixing directly to the frame for maximum insulation and draught proofing. When using Easyglaze ensure there is at least 15mm of flat mounting surface around each side of the glass to take the adhesive base section.

Complete packs can be supplied directly from us or alternatively, packs and single lengths can be purchased from our website [www.secondarydiyglazing.com](http://www.secondarydiyglazing.com) via the Easyglaze secondary glazing page.



**HELPFUL HINTS** - To achieve a neat mitre, insert a small piece of mitre beading between the base and cover strip at the point where the mitre is to be cut. Cut the mitre through all sections. This beading has the effect of holding the cover strip at the correct angle so that when applied to the sheet it results in a neat mitre.

**TOOLS REQUIRED** - A fine toothed saw, mitre block, pencil and tape measure.



#### Measuring up for your Plastic Sheeting


1. Measure the existing window pane, vertically (measurement A) and horizontally (measurement B). This is the visible glass only and does not include any frame.
2. Add 12mm to each measurement A & B. This will give you the size of the sheeting required. Also ensure you have the minimum 15mm mounting surface on each side of your window.

#### Measuring up for your Easyglaze

3. You will require 2 lengths at measurement A plus 25mm and 2 lengths at measurement B plus 25mm for your window. Add these together to find out how many of each size of lengths you will need.

#### USING EASYGLAZE STEP BY STEP

4. Ensure cover strip is snapped into base section.
5. Working with your glazing panel, measure the side to which you want to place a strip of Easyglaze. Add 13mm to this and squarely cut a length of the Easyglaze to suit. Repeat this step for each side.
6. Insert a small piece of mitre beading between cover and base at the end of the length to be cut. Using the outer corner as a reference point (see Diagram B), cut a 45° mitre using the fine toothed saw and mitre block. Repeat this step for each corner.
7. Now place the Easyglaze onto each edge of the plastic sheet.
8. Hold the panel to the window frame so that it overlaps equally on each edge and make a pencil mark around the panel on the frame.
9. Using a suitable cleaner, such as Easyfix<sup>®</sup> Surface Preparation Wipes, clean the window surround to ensure a grease-free surface, this provides the best results for the adhesion of the tape. Make sure the window is perfectly dry.
10. Remove the Easyglaze from the panel and separate the base and top sections (mark which top goes with which bottom section). Peel back a couple of centimetres or so of the backing tape, fold out, then position the base section just inside the pencil mark. Check the corners are neat and square then pull the backing tape out from under the base and press the strip firmly in place.
11. Once all four sides are complete, offer the plastic sheet to the window frame. Then insert the top section to hold it in place by tapping in one end and then pressing along the length from this point.



**PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE CUTTING OR FITTING ANY SYSTEM**

TUBEWAY (SALES) LIMITED, Elton Park, Hadleigh Road, Ipswich, IP2 0HN. Tel: 01473 251051 Fax: 01473 236044  
Buy online at [www.secondarydiyglazing.com](http://www.secondarydiyglazing.com) email: [sales@tubeway.co.uk](mailto:sales@tubeway.co.uk) website: [www.tubewaysales.com](http://www.tubewaysales.com)